

Alcove Bathtuk

For all Models



# **Aura Alcove Bathtub**

**Installation Manual** 

# Installation Manual

Please read notices on following page





# **AURA**

Alcove Bathtub

For all Models

# MATERIALS AND TOOLS REQUIRED

### **GENERAL INSTRUCTIONS**


- Read this guide carefully and completely before proceeding.
- It is recommended that you wear safety glasses during the installation.

### NOTICE

- For best results, we recommend that a licensed, professional plumber installs this unit.
- Please read over these instructions thoroughly before beginning installation.
- Make sure that you have all tools and supplies needed to complete the installation.
- Please check local building code.
- Keep receipts (proof of purchase and place of purchase) for this product. The receipt is required should it be necessary to request warranty parts.

### MAINTENACE & CARE

- For best results, we recommend that a licensed, professional plumber installs this unit.
- Do not use any abrasive chemical or corrisve powders, detergents, window cleans, disinfectants or any other strong cleaners on your product as they will destroy the finished and therefore void the warranty.



Pencil

**Drop Cloth** 

Square



ITEM	DESCRIPTION	QTY
1	Alcove Bathtub	1
2	ATO140 Drain (Not Included)	0
3	Metal Strap	2
4		


# ATTENTION!


Please Note: The bathtub has an embedded overflow



Alcove Bathtub

For all Models







Alcove Bathtub

For all Models




# ATTENTION!

**REMOVE ANY OBSTRUCTIONS** 


# **PREPARATION**

1A. Make sure the studs are straight and square



# POSITIONING BATHTUB

**2A.** After carefully verifying the drain location , drill the drain hole.



# ATTENTION!

Picture for reference only. For actual measurements, refer to product's specificiation sheet.

# Alcove Bathtub


# AURA


# For all Models




# **BATHTUB INSTALLATION**

**3A.** If the floor is not flat or level, it is recommended to deposit a mortar bed where the base will be positioned.







# ATTENTION!

The bathtub must never be supported by a wood stud underneath the tilling flange, but by the legs by the floor only.

# AURA

Alcove Bathtub

For all Models



# LEVELING THE BATHTUB

**4A.** Use a level and a bracket to make sure that the bathtub is straight and perpendicular.

# ATTENTION!


Bathtub bottom must be in contact with a perfectly straight and level surface.




**5A.** After installing the drain onto the tub. Use metal hanger straps (¾" x 8") to be attached to the back corners of the bathtubm to secure it against the studs.

# **ATTENTION!**

Attach metal strap with short screws into a wood block 1 12" x 1 12" glued underneath the tilling flange.







# Alcove Bathtub

# For all Models



# SILCONING THE BATHTUB

**6A.** Apply 100% silicon sealer to any gaps in the corners and seal the joint between the bathtub and the wall finish.

# ATTENTION!

Allow the sealant to dry for at least 24



- 1. Framing
- 2. Dray Wall
- 3. Finished Wall
- 4. Sealant
- 5. Bathtub
- 6. Wood Block 1 1/2" x 1 1/2"
- 7. Metal Strap

